

# **CURSOR SERIES**

**Industrial application**

**C78**

**C78 ENT**

This publication describes the characteristics, data and correct methods for repair operations on each component of the vehicle.

If the instructions provided are followed and the specified equipment is used, correct repair operations in the programmed time will be ensured, safeguarding against possible accidents.

Before starting to perform whatever type of repair, ensure that all accident prevention equipment is available and efficient.

All protections specified by safety regulations, i.e.: goggles, helmet, gloves, boot, etc. must be checked and worn.

All machining, lifting and conveying equipment should be inspected before use.

The data contained in this publication was correct at the time of going to press but due to possible modifications made by the Manufacturer for reasons of a technical or commercial nature or for adaptation to the legal requirements of the different countries, some changes may have occurred.

No part of this publication, including the pictures, may be reproduced in any form or by any means.

Publication edited by  
Iveco Motors  
Iveco SpA  
PowerTrain  
Mkt. Advertising & Promotion  
Viale dell'Industria, 15/17  
20010 Pregnana Milanese  
Milano (Italy)  
Print **P2D32C001GB/W** - 1<sup>st</sup> Ed. 11.2004  
**C78 ENT Series**

Produced by:


















B.U. TECHNICAL PUBLISHING  
Iveco Technical Publications  
Lungo Stura Lazio, 15/19  
10156 Turin - Italy

**CORRESPONDENCE BETWEEN TECHNICAL CODE AND COMMERCIAL CODE**

Technical Code	Commercial Code
F2BE0687A*B101	C78 ENT

## SPECIFICATIONS

	Type	<b>C78 ENT SERIES</b>	
	Cycle	4-stroke Diesel engine	
	Fuel feed	Turbocharged	
	Injection	Direct	
	No. of cylinders	6 in line	
	Bore	mm	115
	Stroke	mm	125
	Total displacement	cm <sup>3</sup>	7790
	VALVE TIMING		
	opens before T.D.C.	A	17°
	closes after B.D.C.	B	31°
	opens before B.D.C.	D	48°
	closes after T.D.C.	C	9°
	For timing check	X	mm
			mm
	Running	X	mm
			mm
	FEED	Through fuel pump - filters	
	Injection type: Bosch	With electronically regulated injectors PDE 30 pump injectors controlled by overhead camshaft MS6.2 ECU	
	Nozzle type	-	
	Injection order	1 - 4 - 2 - 6 - 3 - 5	
	Injection pressure	bar	1500
	Injector calibration	bar	290 ± 12








C78 ENT Series engines			TECHNICAL CODE
	Type		F2BE0687A*B101
$Q$	Compression ratio		16 ± 0.8
 	Max. output	kW (HP) rpm	220 (300) 2200
 	Max. torque	Nm (kgm) rpm	1250 (125) 1200
	Loadless engine idling	rpm	900
	Loadless engine peak	rpm	2430
	Bore x stroke Displacement	mm cm <sup>3</sup>	115 x 125 7790
	<b>SUPERCHARGING</b>  Turbocharger type		Intercooler Direct injection  HX40W
	<b>LUBRICATION</b>  Oil pressure (warm engine)  - idling - peak rpm	bar  bar bar	Forced by gear pump, relief valve single action oil filter  4 5
	<b>COOLING</b> Water pump control <b>Thermostat</b> - start of opening	°C	Liquid Through belt  85










Data, features and performances are valid only if the technician fully complies with all the installation requirements provided by Iveco Motors.











Furthermore, the use of the unit after overhaul should conform to the original specified power and engine rev/min for which the engine has been designed.

**ASSEMBLY CLEARANCE DATA**







 Type	<b>C78 ENT SERIES</b>	
<b>CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS</b>	mm	
 Cylinder sleeve bore upper lower	$\varnothing 1$	130.200 to 130.225 128.510 to 128.535
 Cylinder liners: outer diameter: length	$\varnothing 2$ L	upper lower L 130.161 to 130.186 128.475 to 128.500
 Cylinder sleeve - crankcase bore	upper lower	0.014 to 0.064 0.010 to 0.060
  Outside diameter	$\varnothing 2$	
 Cylinder sleeve inside diameter $\varnothing 3$ inside diameter $\varnothing 3$ Protrusion	A* B* X	115.000 to 115.012 115.010 to 115.022 0.035 to 0.065
* Available dia. class		
 Pistons: measuring dimension outside diameter $\varnothing 1$ A• outside diameter $\varnothing 1$ B•• outside diameter $\varnothing 2$	X X • •• X	18 114.888 to 114.900 114.898 to 114.910 46.010 to 46.018 114.898 to 114.910
• Class A pistons supplied as spares. •• Class B pistons are fitted in production only and are not supplied as spares.		
 Piston - cylinder sleeve		0.100 to 0.124
  Piston diameter	$\varnothing 1$	-
 Pistons protrusion	X	-
 Gudgeon pin	$\varnothing 3$	45.994 to 46.000
 Gudgeon pin - pin housing		0.010 to 0.024









	Type	<b>C78 ENT SERIES</b>					
<b>CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS</b>		mm					
	Piston ring grooves *measured on $\varnothing$ of 112 mm	X1* X2 X3	2.71 to 2.74 2.55 to 2.57 4.02 to 4.04				
	Piston rings: trapezoidal seal lune seal milled scraper ring with slits and internal spring *measured on $\varnothing$ of 112 mm	S1* S2 S3	2.575 to 2.595 2.470 to 2.490 3.975 to 3.990				
	Piston rings - grooves	1 2 3	0.115 to 0.165 0.060 to 0.100 0.030 to 0.065				
	Piston rings		-				
	Piston ring end gap in cylinder liners:	X1 X2 X3	0.35 to 0.50 0.70 to 0.95 0.30 to 0.60				
	Small end bush housing Big end bearing housing Selection classes $\varnothing 2$	$\varnothing 1$ $\varnothing 2$ <table border="0" style="display: inline-table; vertical-align: middle;"> <tr><td rowspan="3" style="font-size: 3em; vertical-align: middle;">}</td><td>1</td></tr> <tr><td>2</td></tr> <tr><td>3</td></tr> </table>	}	1	2	3	49.975 to 50.000 77.000 to 77.030 77.000 to 77.010 77.010 to 77.020 77.020 to 77.030
}	1						
	2						
	3						
	Small end bush diameter outside inside Big end bearing shell Red Green Yellow●	$\varnothing 4$ $\varnothing 3$ S	50.055 to 50.080 46.015 to 46.030 2.000 to 2.010 2.011 to 2.020 2.021 to 2.030				
	Small end bush - housing		0.055 to 0.105				
	Piston pin - bush		0.015 to 0.036				
	Big end bearing shells		0.127 - 0.254 - 0.508				
	Connecting rod weight Class	A B C	g 2890 to 2920 2921 to 2950 2951 to 2980				













- Fitted in production only and not supplied as spares


 Type	C78 ENT SERIES	
<b>CYLINDER BLOCK AND CRANK MECHANISM COMPONENTS</b>	mm	
 Measuring dimension X	X	125
 Max. connecting rod axis misalignment tolerance	=	0.08
 Main journals - nominal - class - class - class   Crankpins - nominal - class - class - class   Main bearing shells Red Green Yellow●   Big end bearing shells Red Green Yellow●	Ø1 1 2 3  Ø2 Ø2 1 2 3  S1 S2	82.910 to 82.940 82.910 to 82.919 82.920 to 82.929 82.930 to 82.940  72.915 to 72.945 72.915 to 72.924 72.925 to 72.934 72.935 to 72.945  3.000 to 3.010 3.011 to 3.020 3.021 to 3.030  2.000 to 2.010 2.011 to 2.020 2.021 to 2.030
 Main bearing housings	Ø3 1 2 3	89.000 to 89.030 89.000 to 89.009 89.010 to 89.019 89.020 to 89.030
 Bearing shells - main journals		0.040 to 0.098
 Bearing shells - big ends		0.035 to 0.093
 Main bearing shells Big end bearing shells		0.127 - 0.254 - 0.508 0.127 - 0.254 - 0.508
 Main journal, thrust bearing	X1	39.96 to 40.04
 Main bearing housing, thrust bearing	X2	32.94 to 32.99
 Thrust washer halves	X3	3.38 to 3.43
 Driving shaft shoulder		0.11 to 0.34
 Alignment Ovality Taper	} = 1 - 2 } ○ 1 - 2 } > 1 - 2	≤ 0.05 _0.010 0.010

● Fitted in production only and not supplied as spares


 Type	<b>C78 ENT SERIES</b>	
<b>CYLINDER HEADS - VALVE TRAIN</b>		
mm		
 Valve guide housings in cylinder head	$\varnothing 1$	12.980 to 12.997
 Valve guide	$\varnothing 2$ $\varnothing 3$	8.023 to 8.038 13.012 to 13.025
 Valve guides - housings in the cylinder heads		0.015 to 0.045
 Valve guide		-
Valves: 	$\varnothing 4$ $\alpha$ $\varnothing 4$ $\alpha$	7.970 to 8.985 $60^{\circ} 30' \pm 7' 30''$ 7.970 to 8.985 $45^{\circ} + 15'$
 Valve stem and its guide		0.038 to 0.068
Housing in head for valve seat 	$\varnothing 1$ $\varnothing 1$	41.985 to 42.020 40.985 to 41.020
Outside diameter of valve seat; angle of valve seat in cylinder head: 	$\varnothing 2$ $\alpha$ $\varnothing 2$ $\alpha$	42.060 to 42.075 $60^{\circ} - 30'$ 41.060 to 41.075 $45^{\circ} - 30'$
Recessing of valve 	$\varnothing 2$ $\varnothing 2$	0.5 to 0.8 1.6 to 1.9
 Between valve seat and head	$\varnothing 2$ $\varnothing 2$	0.040 to 0.090

 Type	<b>C78 ENT SERIES</b>	
<b>CYLINDER HEADS - VALVE TRAIN</b>	mm	
 Valve outside spring height: free height H under a load of: N 454 ± 22 H1 N 840 ± 42 H2		62.6 48.5 36.5
 Injector protrusion X		0.7
 Camshaft bush housing fitted in the cylinder head: l ⇒ 7 Ø		80.000 to 80.030
 Camshaft journal diameter: l ⇒ 7 Ø		75.924 to 75.940
 Camshaft bushing outer diameter: Ø		80.090 to 80.115
 Camshaft bushing inner diameter: Ø		75.990 to 76.045
 Bushings and housings in engine block		0.060 to 0.115
 Bushings and journals		0.050 to 0.121
Cam lift: 		8.07 7.63 8.80 to 8.82
 Rocker shaft Ø 1		37.984 to 38.000


 Type	<b>C78 ENT SERIES</b>
<b>CYLINDER HEADS - VALVE TRAIN</b>	mm
Bushing housing in rocker arms    	41.000 to 41.016 41.000 to 41.016 42.000 to 42.016
Bushing outer diameter for rocker arms:    	41.097 to 41.135 41.097 to 41.135 42.066 to 42.091
Bushing inner diameter for rocker arms:    	38.025 to 38.041 38.025 to 38.041 38.015 to 38.071
Between bushings and housings    	0.081 to 0.135 0.081 to 0.135 0.050 to 0.091
Between rocker arms and shaft    	0.025 to 0.057 0.225 to 0.057 0.015 to 0.087
<b>TURBOCHARGER</b> Type End float Radial play	HOLSET HX40W - -

**TOOLS****TOOL NO.** **DESCRIPTION****8093731**


Tester PT01

**99305019**


Full-optional tool-kit to rectify valve seat

**99305047**


Equipment for spring load check

**99322230**

Rotary telescopic stand

**99340051**

Extractor for crankshaft front gasket


**99340052**

Extractor for crankshaft rear gasket


**TOOLS**

TOOL NO.

DESCRIPTION

**99340205**


Percussion extractor

**99342148**


Injector extractor

**99342149**


Extractor for injector-holder

**99346245**

Tool to install the crankshaft front gasket

**99346246**

Tool to install the crankshaft rear gasket


**99348004**

Universal extractor for 5 to 70 mm internal components


**TOOLS**

TOOL NO.


DESCRIPTION

**99350072**


Box wrench for transmission gear support fixing screws

**99350074**


Box wrench for block junction bolts to the underblock

**99360144**


Skid retaining tools (12+6) for rocker arm adjusting screws during rocker arm shaft removal/ refitting

**99360177**

Injector housing plug

**99360184**

Pincers for removing and refitting circlips and pistons (105-160 mm)


**99360264**

Tool to take down-fit engine valves


**TOOLS**

TOOL NO.


DESCRIPTION

**99360288**


Tool to remove valve guide

**99360292**


Tool to install gasket on valve guide

**99360294**


Tool to drive valve guide

**99360314**

Tool to remove cartridge filters

**99360321**

Tool to rotate engine flywheel


**99360334**

Tool for checking cylinder barrel projection.


**TOOLS**

TOOL NO.


DESCRIPTION

**99360335**


Cylinder barrel compression cap (to be used with 99360334)

**99360351**

Tool to stop engine flywheel

**99360487**


Tool to take down and fit back camshaft bushes

**99360500**

Tool to lift crankshaft

**99360551**

Bracket to take down and fit engine flywheel


**99360558**

Tool to lift and transport rocker shaft


**TOOLS**

TOOL NO.


DESCRIPTION

**99360585**


Balance for lifting and handling engine

**99360605**


Belt to insert piston in cylinder liner (60 - 125 mm)

**99360612**


Engine flywheel timing pin

**99360613**

Tool for timing of phonic wheel on timing gear

**99360703**

Tool to stop cylinder liners


**99360706**

Tool to extract cylinder liners


**TOOLS**

TOOL NO.


DESCRIPTION

**99360724**



Tool to extract the cylinder liners (to be used with 99360723)

**99361035**

Brackets fixing the engine to rotary stand 99322230


**99365054**

Tool for injector holder heading

**99370415**Tool to detect cylinder liner projections  
(use with 99395603)**99378100**

Tool for printing engine identification plates (to be used with special punches)

**99378101 \***  
**99378102 •**  
**99378105 ■**  
**99378106 ▲**

Punches (**A\*** - **B•** - **E■** - **F▲**) for printing engine identification plates (to be used with 99378100)

**TOOLS**

TOOL NO.	DESCRIPTION
<b>99389834</b>	Dynamometric screwdriver to calibrate screws for injector solenoid valve
<b>99390310</b>	Valve guide sleeker
<b>99390772</b>	Tool to remove residues from injector holder
<b>99390804</b>	Tool to thread injector holders to be extracted
<b>99394014</b>	Guide bush (to be used with 99394041 or 99394043)
<b>99394041</b>	Cutter to rectify injector holder housing (to be used with 99394015)


**TOOLS**

TOOL NO.	DESCRIPTION
<b>99394043</b>	Reamer to rectify injector holder lower side (to be used with 99394015)
<b>99395215</b>	Gauge for centre distance check between camshaft and idle gear
<b>99395216</b>	Measuring pair for angular tightening with 1/2" and 3/4" square couplings
<b>99395363</b>	Complete square to check connecting rod squaring
<b>99395603</b>	Dial gauge (0 - 5 mm)
<b>99395687</b>	Reaming gauge (50-178 mm)

**TOOLS**

TOOL NO.

DESCRIPTION

**99396033**

Centering ring of crankshaft front cap

